

INSTALLATION INSTRUCTIONS

PART No.

FB22080

Jeep® CJ-YJ Wrangler 1976-1996 Piranha Front Bumper











REQUIRED TOOLS

19mm wrench

KIT CONTAINS	QT
Bumper	1
½" Hex bolt	6
½" Flat washer	6
Spacer (CJ only)	2
D-rings	2

2208000



INSTALLATION INSTRUCTIONS

PART No.

FB22080

Jeep® CJ-YJ Wrangler 1976-1996 Piranha Front Bumper

1) REMOVE YOUR FACTORY OR AFTERMARKET BUMPER

Begin by removing your factory or aftermarket bumper and frame cover.



2) INSTALL YOUR BUMPER

Rest your bumper on the Jeep's frame rails and center it. Using the supplied hardware, loosely install the top four (4) bolts and washers.

NOTE: The CJ will use the four (4) inner holes and the YJ will use the four (4) outer holes.



For a CJ, place the supplied spacers underneath the frame between the frame and bumper, to fill the gap. Install the remaining hardware underneath and proceed to tightening all hardware using a 19mm wrench.



For a YJ, simply install the lower hardware and proceed to tightening all hardware.



3) MOUNT YOUR D-RINGS



4) ENJOY YOUR NEW FISHBONE OFFROAD BUMPER!